U241E AUTOMATIC TRANSAXLE

SST

		T	
	09308-00010	Oil Seal Puller	-
	09316-60011	Transmission & Transfer Bearing Replacer	-
- C-	(09316-00011)	Replacer Pipe	-
	09350-32014	TOYOTA Automatic Transmission Tool Set	-
	(09351-32010)	One-way Clutch Test Tool	-
	(09351-32020)	Stator Stopper	-
	(09351-32070)	No.2 Piston Spring Compressor	-
	(09351-3240)	Oil Seal Replacer	-
	(09351-32150)	Oil Seal Replacer	-
	09387-00020	Direct Clutch Wrench	-
	09387-00030	Counter Drive Gear Holding Tool	-



		1	1
	09387-00041	Bearing Puller Assembly	-
	(09387-01010)	Claw No.1	-
	(09387-01030)	Pin	-
	(09387-01040)	Bearing Puller Body	-
	(09387-02010)	Oil Seal Replacer	-
	(09387-02020)	One-way Clutch Test Tool Set	-
	09387-00050	Under Drive Gear Puller	-
	09387-00060	Second Brake Wrench	-
	09387-00070	First & Reverse Brake Wrench	-
	09387-00080	Counter Drive Gear Nut Wrench	-
0			
	09506-35010	Differential Drive Pinion Rear Bearing Replacer	-
		Souring Replaces	
	09514-35011	Rear Wheel Bearing Puller	-



		T	, ·
	09550-60010	Differential Side Bearing Replacer	-
	(09951-00320)	Replacer 32	-
(a)	, ,		
	09564-16020	Drive Pinion Lock Nut Wrench	-
	09564-32011	Differential Preload Adaptor	-
-	09608-06041	Front Hub Inner Bearing Cone	-
	09608-06041	Replacer	
	09608-32010	Steering Knuckle Oil Seal	-
		Replacer	
	09649-17010	Steering Knuckle Tool	-
	09930-00010	Drive Shaft Nut Chisel	-
	(09931-00010)	Handle	-
	(09931-00020)	Nut Chisel	-
	09950-00020	Bearing Remover	-
	09950-00030	Bearing Remover Attachment	-



	T		
20 20 and	09950-40011	Puller B Set	-
	(09951-04010)	Hanger 150	-
	(
	(09951-04020)	Hanger 200	-
	(09952-04010)	Slide Arm	-
	(09953-04020)	Center Bolt 150	-
	(09954-04010)	Arm 25	-
	(09955-04011)	Claw No.1	-
	(09955-04061)	Claw No.6	-
	(09957-04010)	Attachment	-
❷			
	(09958-04011)	Holder	-
	09950-60010	Replacer Set	-
CORRESPONDED OF THE PROPERTY O			
	(09951-00230)	Replacer 23	-
9			



			T
	(09951-00250)	Replacer 25	-
9			
	(09951-00320)	Replacer 32	-
(2)			
	(00054 00040)	Pouls of 04	
	(09951-00340)	Replacer 34	-
	(09951-00350)	Replacer 35	-
(a)			
	(09951-00400)	Replacer 40	-
(a)			
	(09951-00450)	Replacer 45	-
	(09951-00600)	Replacer 60	-
•			
	09950-60020	Replacer Set No.2	-
0000 0000 0000			
	(09951-00680)	Replacer 68	-
6			
	(09951-00710)	Replacer 71	-
(a)			
	(09951-00890)	Replacer 89	-
6			
	(09951-07150)	Handle 150	-

PP

	09950-70010	Handle Set	-
	(09951-07100)	Handle 100	-
	(09951-07150)	Handle 150	-
٩			



RECOMMENDED TOOLS

		T	1
	09011-12301	Socket Wrench 30 mm	-
	09031-00030	Pin Punch	-
	09040-00011	Hexagon Wrench Set	-
The state of the s			
	(09043-20060)	Socket Hexagon Wrench 6	-
	(09043-20100)	Socket Hexagon Wrench 10	-
	09042-00010	Torx Socket T30	-
	09904-00010	Expander Set	-
Manager 1979			
	09905-00012	Snap Ring No.1 Expander	-
	09905-00013	Snap Ring Pliers	-



EQUIPMENT

Straight edge	-
Vernier calipers	-
Dial indicator or dial indicator with magnetic base	-
Torque wrench	-
Feeler gauge	-
Plastic-faced hammer	-
Press	-
Seal packing 2403, THREE BOND 2403 or equivalent	-



LUBRICANT

Automatic transaxle fluid Dry fill	8.1 liters (8.6 US qts, 7.2 Imp. qts)	Toyota Genuine ATF WS
Automatic transaxle fluid Drain and refill	3.5 liters (3.7 US qts, 3.1 lmp. qts)	



SSM

Toyota Genuine Seal Packing 1281 Three Bond 1281 or Equivalent	-
Toyota Genuine Adhesive 1344 Three Bond 1344 or Equivalent	-

